

Ballast Controllers



Description

Helvar ballast controllers allow analogue and other non-DALI controllable electronic ballasts to be integrated to DIGIDIM, DALI and Imagine systems. The range covers multichannel ballasts controllers for DIN-rail, Helvar 458 Series and Imagine rack systems.

Product Type

- 1-10V
- 0-10V
- Dali